

“RONSTEER” STEERING DEVICE

NZ Patent #587673



INSTRUCTIONS:

- Attach chains with bow shackles (with the pin down from the top) to the extreme left and extreme right holes of the steering delta.
- Ensure there are no twists in the chain
- Attach longline to the stainless steel ring by means of a D-shackle or carabiner (or similar device).
- When launching the kontiki, point the nose of the craft in the direction you want it to go, making allowance for drift and wind etc.

Contact Ken:

www.kentiki.co.nz

06 343 7905

027 2000 692